

## HOW TO INSTALL ROLLER SCREENS WITH SILICONE



Run a bead of silicone around the frame where the roller screen is going to be installed.



The silicone is only needed on the sides and top to secure the cassette and side guides.



This picture shows the cassette and side guides ready to be slot together.

Slide the cassette into the side guide as below.





Once the cassette and guides are slotted together offer them to the window frame and firmly seal to the silicone adhesive, checking the operation once in place.

Don't worry if you need to adjust the screen as the silicone will stay flexible.

If you ever need to remove the screen just run a sharp blade between the screen and frame, the silicone will never set hard.





